How to measure your pool

Simply decide on the essential details,

(1) type of cover (2) roller system

(3) pool size: length (B) X width (A) (+ step area)

= Total square metres.

Ask for a quote let's say - 52m2 S8B with an ST roller.

Take into account if your pool is indoors or outside. Do you need more heat or less or have leaf debris. Remember your roller adds years to the life of the cover. Does your pool have non-standard features? These are some determining facts you need to discuss with us.

